














SIGMA SPORT BASELINE 700



Printed in Germany




CHANGE FUNCTION




**RESET: TRP + STP
AVS + MAX**




SET WS



SET CLK



SET DST



nach Batteriewechsel
 after battery change
 après change de piles
 after wisselen de batterijen
 dopo sostituzione delle pile
 cada cambio de pilas